




This manual will guide you through the development of a first, simple FESA3 class







Design

- specify public interface
- specify internal data
- specify RT actions

C++ Code

- implement RT actions
- build class library

Binary

- define deployment unit
- define process type
- configure scheduling
- compile and link binary

Now we will start to fill our empty class design. The goal is to design a class which generates one random number per second.


data	
device-data	
setting	
field	
persistent	true
name	randomNumberMax
multiplexed	false
scalar	
type	int32_t
acquisition	
field	
name	randomNumber
multiplexed	false
scalar	
type	int32_t

We start with defining the definition of the needed data-containers. Just add all missing elements, like shown in the picture. (right-click-->add-child)

The random number itself is stored as "acquisition" data, since we want to send it to the client.

The maximum number which can be generated shall be configurable by the client. So we choose to store it as "setting"-data.

Click on each element to view the HTML documentation in the Eclipse-Browser!



Design

- specify public interface
- specify internal data
- specify RT actions

C++ Code

- implement RT actions
- build class library

In order to provide client-read-access to the defined internal data, we need to add properties in the “interface”-part of our class.

interface	
device-interface	(setting?, acquisition?)
setting	
acquisition	((acquisition-property?))
acquisition-property	
visibility	operational
name	RandomNumber
multiplexed	false
value-item	
name	randomNumber
direction	OUT
scalar	
type	int32_t
data-field-ref	
field-name-ref	randomNumber
get-action	(server-action-ref acquisition-property?)
server-action-ref	
server-action-name	GetRandomNumber

We define an acquisition-property, which can be read by the client via “Get” or “Subscribe”.

Value-Items are used to outline which data is transferred by a property. Here we connect the value-item to our field, in order to transfer our internal data.

Only the elements which need to be modified are shown here !!

The `get-action` models the C++ implementation of the data-transfer. Note that the XML file will show an error as long as the action does not exist:

actions	
get-server-action	
implementation	default
name	GetRandomNumber

get-action	
server-action-ref	
server-action-name	GetRandomNumber


You can check the concrete error message in the “source”-view. (click on red dot)

```

69     </cycle-stamp-item>
70     <get-action>
71       <server-action-ref server-action-name-ref="GetRandomNumber" />
72     </get-action>
73   </acquisition-property></acquisition></device-interface>

```

Validate your FESA class design with the  validate button !



Design

- specify public interface
- specify internal data
- specify RT actions

C++ Code

- implement RT actions
- build class library

Now we proceed in the same way for our setting-field "randomNumberMax", in order to give the client write-access to it..

▼ e set-server-action	(((description*), (disabling-...
@ implementation	default
@ name	SetRandomNumberLimits
▼ e get-server-action	(((description*), (disabling-...
@ implementation	default
@ name	GetRandomNumberLimits


This time we start with the actions, in order to use the auto-completion feature.

Again we choose implementation = "default". So we don't need to provide own C++ code for this action.

▼ e interface	(device-interface?, global-i...
▼ e device-interface	(setting?, acquisition?)
▼ e setting	((command-property*, sett...
▼ e setting-property	((description*), (filter-item*
@ multiplexed	false
@ name	RandomNumberLimits
@ visibility	operational
▼ e value-item	((description*, (scalar arr...
@ direction	INOUT
@ name	randomNumberMax
▼ e scalar	
@ type	int32_t
▼ e data-field-ref	
@ field-name-ref	randomNumberMax
▼ e set-action	(server-action-ref abstract
▼ e server-action-ref	
@ server-action-name-ref	SetRandomNumberLimits
▼ e get-action	(server-action-ref abstract
▼ e server-action-ref	
@ server-action-name-ref	GetRandomNumberLimits

A setting-property can be written by a client with "Set" or re-read via "Get".

Note that now you can choose the **get-** and **set-**actions from a list, because we defined the actions in advance.



Design

- specify public interface
- specify internal data
- specify RT actions

C++ Code

- implement RT actions
- build class library

Finally we will design the random number generation itself. For this purpose we use a `timer-event-source` which periodically triggers an action.

▼ [e] events	
▼ [e] sources	
▶ [e] timing-event-source	
▶ [e] timer-event-source	
▼ [e] logical-events	
▼ [e] logical-event	
ⓐ use	required
ⓐ name	timerEvent
ⓐ type	timer



First we define the `event-source` and the `logical-event` which is used by this source. Right-click on the root-element "equipment-model" in order to add the element "`events`".

▼ [e] actions	
▼ [e] rt-action	
ⓐ name	GenerateRandomNumber
▼ [e] notified-property	
ⓐ property-name-ref	RandomNumber
ⓐ automatic	true

All actions which do not interact with the client are called "`rt-action`". This is what we need for the number generation. We as well choose to automatically notify all clients which subscribed to our property "`GetRandomNumber`".

▼ [e] scheduling-units	
▼ [e] scheduling-unit	
ⓐ name	TimerSchedulingUnit
▼ [e] rt-action-ref	
ⓐ rt-action-name-ref	GenerateRandomNumber
▼ [e] logical-event-ref	
ⓐ logical-event-name-ref	timerEvent

In order to connect our `rt-action` with the `logical-event`, we need to add a "`scheduling-unit`". Again right-click on the root-element in order to add the element "`scheduling-units`".

Finally you finished the design-phase! Now re-check if your design is valid by pressing  and `fix all remaining bugs`. After that, trigger the `code generation` by pressing the  button. This will generate the C++ source code skeleton of your class.

As next step we will add some C++ code in order to generate the random-numbers itself. To do so, open the file “[HandsOnClass/src/HandsOnClass/RealTime/GenerateRandomNumber.cpp](#)” from the Eclipse-Project-Explorer and modify it, according to the source-code below.

After you finished the implementation you can **compile** your FESA class library. Go to the project folder and execute the make target „all x86_64“. This can be done in Eclipse using the „Make Targets“ view in the FESA or C++ perspective.

By executing the target „clean“ you can remove all object files and libraries from previous builds.

- all i686
- all x86_64
- clean

C++ Code

- implement RT actions
- build class library

```
void GenerateRandomNumber::execute(fesa::RTEvt* pEvt)
{
    std::vector<Device*>::iterator device;
    for(device=deviceCol_.begin();device!=deviceCol_.end();++device)
    {
        // get upper limit for random-numbers from internal field
        int32_t rand_max = (*device)->randomNumberMax.get(pEvt->getMultiplexingContext());

        // generate random-number between 0 and rand_max
        int32_t rand_number = rand() % ( rand_max + 1 );

        // produce some output
        std::ostringstream message;
        message << " Produced random number: " << rand_number << " for device: " << (*device)->getName();
        LOG_TRACE_IF(logger, message.str());

        // save produced random-number in internal field
        (*device)->randomNumber.set(rand_number,pEvt->getMultiplexingContext());
    }
}
```

You may want to copy + paste this source code!

A FESA binary is built from **any number of FESA classes** and **one FESA deploy-unit**. Each class describes one equipment component. The deploy-unit is needed to couple all these classes.
 To create a deploy-unit project, choose: **File → New → Project.. → FESA → New FESA Deploy Unit**.
 According to the class we name it “**HandsOnDeployUnit**”.

▼ e class	
e class-name	HandsOnClass
e class-major-version	0
e class-minor-version	1
e class-tiny-version	0
e device-instance	required
▼ e executable	
▼ e mixed	
a extension	_M

Only the items that you need to add or change are listed here. When you finished editing the deployment document, **validate** 🌍 it and **generate** 🔄 the **C++ source code**.


To generate the executable FESA binary execute the make target „all x86_64“ as well for the deploy-unit.

▼ e scheduler	(concurrency-layer)+
▼ e concurrency-layer	(scheduling-unit)+
a name	TimerLayer
a prio	19
▼ e scheduling-unit	
a per-device-group	no
a scheduling-unit-name-ref	HandsOnClass::TimerSchedulingUnit

Note: After adding the class name, **save the document**. The plug-in will automatically add the elements “path” and “include”. Now you will be able to pick the desired scheduling-unit from a list.

Binary

- define deployment unit
- define process type
- configure scheduling
- compile and link binary


For the next step you need to configure on which front-end (FEC) your binary should run. To do so, open the deploy-unit document and push the „Add FEC“  button. Put in the hostname of the front-end on which you currently work. Select the timing network 'NONE'.

▼ e classes	
▼ e HandsOnClass	
▶ e multiplexing	
▼ e events-mapping	
▼ e timerEvent	
▼ e event-configuration	
ⓐ name	OncePerSecond
▼ e Timer	
▼ e timer-event	
ⓐ period	1000
▶ e unused-event-configuratio	

Configure the devices of your class as shown on the screenshots.

▼ e prio-management	
▼ e classes	
▼ e HandsOnClass	
▼ e client-notification-threads	
▼ e thread-default	
ⓐ prio	1


Note that we use the event-configuration “OncePerSecond” which we defined at our own in the section “events-mapping”.

Validate your instantiation document by pressing .

▼ e HandsOnClass	
▼ e device-instance	
ⓐ name	TestDevice1
▶ e configuration	
▼ e events-mapping	
▼ e timerEvent	
▼ e event-configuration-ref	
ⓐ name	OncePerSecond
▼ e global-instance	
ⓐ name	HandsOnGlobalInstance

Later you can find this file in: HandsOnDeployUnit/src/test/[FEC]

- compile and link binary




Test

- start binary
- launch navigator tool
- check output

Instantiate

- add device instances
- bind logical events
- define init values
- define device names





Once the FESA Explorer is open select the “TestDevice1” and double-click on the property “RandomNumberLimits”. Put a value into the field “randomNumber_max” and press “Set” in order to send the data via the middleware to your class.

Now double-click on the property “RandomNumber” and press “Subscribe”. If you implemented everything in the right way, you should receive one random number per second.

Congratulations!

If you arrived here you finished the FESA3 HandsOn tutorial. On any problems please do not hesitate to check the [FESA Wiki](#) or to contact the [FESA support team](#).

For further training you may want to add a field “randomNumber_min” to your class and write a [custom-server-action](#) which produces additional output. Feel free to extend your class to whatever you want! As well check the [HTML documentation](#) in the [Browser](#) if you face any unknown FESA XML elements.



Test

- start binary
- launch navigator tool
- check output

Instantiate

- instantiate device instance
- define logical events
- define initial values
- define device name